DRIVE MOTOR AND RAM PARTS

KitchenAid®

For Model: KUCS181T1

COMPACTOR



1	4178043	Motor, Drive
2	4161013	Belt, Drive
3	4178086	Sprocket, Driven
4	4159303	Screw, 1/4 20 x 2" (4)
5	4161268	Ram, Top
6	4163107	Ram, Bottom
7	4159414	Screw, 8-18 x 1/2 (4)
8	4159105	Nut, 10-32 (4)
9	4161212	Brace, Top
10	4160983	Chain, Drive
11	4159084	Nut, 5/16-18 (3)
12	4159525	Washer (3)
13	4161041	Stop, Ram Upper
14		Plate, Powerscrew Cover
	4161003	Left Side
	4161002	Right Side
	4161271	Rear
15	4159416	Screw, 10-24 x 1/2
16	4161449	Sprocket, Powerscrew (3)
17	4160988	Powerscrew (3)
18	4162027	Screw, 1/4-20 x 7/16
19	4162026	Stop, Ram Lower (3)
20	4161394	Nut (3)
21	4161390	Retainer, Nut (3)
22	4159364	Screw, 8 x 5/16 (2)
23	4159590	Washer (4)
24	4161121	Sprocket, Idler (4)
25	4159105	Nut, 10-32 (2)
26	4178066	Plate, Idler
27	4161124	Bushing (2)
28		Arm, Idler
	4161122	Left Side
	4161123	Right Side
29	4161133	Spring, Chain Tension
30	4159388	Screw, 10 x 1/2
31	4159494	Washer
32	4161012	Switch, Directional
33	4159353	Screw, 6-32 x 7/8 (2)
34	4160064	Retainer, Wire
35	4178044	Grommet, Wiring
41	9870617	Gear, Drive
42	4178045	Deflector, Debris
43	4159154	Pin, Gear

LITERATURE PARTS

LIT9870117	Instructions, Installation (Built-In Application)
LIT9870159	Diagram, Wiring
LIT9740200	Instructions, Installation (Front Panel)
LIT9740079	Guide, Use and Care

FRAME PARTS

For Model: KUCS161T1



1		Frame (Non-Serviceable)
2	4162329	Motor, Fan
3	4161698	Blade, Fan
4	4159353	Screw, 6-32 x 7/8 (2)
5	4178085	Filter, Air
6	4159416	Screw, 10 x 1/2
7	9870703	Housing, Filter
8	4161673	Gasket, Housing
9	4161216	Switch, Ram Stop
10	4159416	Screw, 10-24 x 1/2
11	4178067	Screw, 6-32 x 1" (2)
12	4159983	Bumper, Door (2)
13	4159104	Nut, 6-32 (2)
14	4162252	Switch, Drawer
15	4162253	Block
16	4162571	Barrier
17	4162310	Bracket
18	4159184	Screw, 10 x 3/8
19	4161363	Foot, leveling (4)
20	4161274	Plate, Frame Cover
21	4159494	Washer
22	776559	Screw, 6 x 3/8 (2)
23	4161101	Plate, Top Front
24	4178050	Bushing
25	4159023	Strain Relief
26	4178049	Bushing (2)
27	4159388	Screw
28	4162025	Strike, Door
29	4160982	Spring, Track (4)
30	4161134	Screw, 1/4-20 x 3/8 (4)
31	4159106	Nut, 1/4-20 (4)
32	4159554	Washer (4)
33		Track, Container
	4162020	Left Side
	4162021	Right Side
34	4159305	Screw, 10-32 x 3/8 (2)
35	4159105	Nut, 10-32 (2)
36	4162616	Litter, Bin
37	4159166	Rivet
38	4159384	Screw, No. 6 x 3/8
39	4161250	Switch, Limit
40	4161165	Baffle
41	4159268	Screw, 4-40 x 5/8
42	4159495	Washer, Lock
43	4159069	Nut
44	9740311	Retainer, Cord
45	9870706	Bracket, Motor

CONTAINER PARTS

For Model: KUCS181T1



1	9870766	Container
2	4161337	Liner, Container
3		Panel, Container
	4178037	White & Almond
	4178039	Harvest Gold & Black
4	4178051	Front, Contianer
5	4162880	Filler, Panel
7	4161232	Plate, Toe
8	4161152	Bracket, Toe Plate
9	4178056	Plate, Relief
10	4161527	Cover, Storage
11	4159387	Screw, 10 x 3/8
12	4161515	Handle, Pull
13	4162881	Bezel, Handle
14	4161542	Bracket, Handle
15	9870260	Latch Assembly
16		Spring, Latch
	4162740	Left Side
	4162739	Right Side
17	4160981	Handle, Container
18		Trim, Front
	4161176	Left Side
	4161173	Right Side
	4161177	Bottom
19	4159439	Screw, 10-32 x 5/16
20	4159105	Nut, 10-32
23	4178087	Screw, #10 x 3/8 (3)
24	4147703	Retainer, Bag (4)
26	4159414	Screw, 10-24 x 3/8
27	342043	Screw, 10-32 x 5/16
28	4159105	Nut, Lock

CABINET AND CONTROL PARTS

For Model: KUCS181T1



1		Panel, Cabinet
	9870732	Left Side
	9870733	Right Side
	9870713	Back
2	4164800	Freestanding, Conversion Kit
3	4161162	Top, Wood
4	4161301	Plate,
5	4159388	Screw, 10 x 1/2
6	4162573	Clamp, Wire
7	4159983	Bumper, Container
8	4159494	Washer
9	4159387	Screw, 10 x 3/8
10	4162882	Switch, Rotary
11	4162883	Nut, Switch
12	4162904	Key, Switch
13	4162891	Switch, Rocker
14	4162569	Cord, Power
15		Harness, Wiring
	4162896	Harness, Main
	4162894	Ram Switch To Key
	4162895	Rocker Switch To Fan Motor
	4161258	Motor Drive To Directional Switch
	4162668	Interlock To Bypass
	4162893	Power Distribution
16	4178077	Escutcheon, Control
17		End Cap
	4162886	Left Side
	4162885	Right Side
18	4178052	Screw, 4 x 1/4 (4)
19	4160981	Handle, Litter Bin
20	4159441	Screw, 10-32 x 5/16
21	4161294	Panel, Litter Bin Rear
22		Trim, Litter Bin
	4161174	Left Side
	4161171	Right Side
	4161177	Bottom
23	4162879	Filler, Bin Panel
24		Insert, Door
	4178036	Almond & White
	4178038	Harvest Wheat & Onyx Black
25	4159503	Washer
26	4178013	Top, Bin
27	4162936	Barrier, Switch
28	690081	Catch, Door
29	4161161	Bracket, Wood Top
30	4159407	Screw, 10 x 1"
31	4159494	Washer (2)
32		Block, Leveling Leg
	4161149	Right Side
	4161150	Left Side
33	4161154	Bracjetm Fiit (4)
34	4159388	Screw 19 x 1/2
35	4161235	Clip, Foot (4)
36	4178064	Clip, Cable
37	4162903	Nut, Speed
38	4159026	Relief, Strain
39	4159031	Relief, 90~ Strain

40	4178076	Bracket
41	4159416	Screw
42	4178083	Clamp, Cord
43	776119	Bushing, Power Cord
44	4319321	Tie, Cable

OPTIONAL PARTS NOT INCLUDED

	4178062	*Panel, Trim-Change Out Kit (White)
	4178063	*Panel, Trim-Change Out Kit (Almond)

CHANGE OUT KITS INCLUDES:

- Fan Switch
- Switch Barrier
- Speed Nut
- Instructions
- Trim Panel

ACCESSORY PARTS

For Model: KUCS181T1



CPK – 4

The Accessory Parts Listed Below May or May Not Be Included With Your Compactor.

1		Bag, Trash (18" Plastic)
	4163345	12 Boxes of 15 Pack
	4163347	1 Box of 15 Pack
	4178058	60 Bags
2		Paint, Spray 13 Oz.
	350956	Almond
	261888	Avocado
	285006	Black
	261886	Coffee
	261890	Harvest Gold
	285366	Platinum
	675167	Electro Tan
	978726	Stanford Brown
	285365	Toast
	350930	White
3		Paint, Touch-Up 1/2 Oz.
	72107	Almond
	72109	Avocado
	72032	Black
	72108	Coffee
	72110	Golden Wheat
	72113	Platinum
	72106	Stanford Brown
	72112	Toast
	72107	White
4	777635	Deodorizer Solid Stick-ups (2 Pack)
5	675351	Grease, 4 Oz. (Use On ower Screw & Ram Pressure Pads)
6		Wire, 25' Roll
	10875	Blue 16 Ga.
	242820	Black 14 Ga.
	242825	Red 14 Ga.
	242826	White 14 Ga.
	47261	Black 12 Ga.
7	279368	Adhesive, Insulation (2 Oz. Tube)